



# QUICK GUIDE ON HOW TO INSTALL DRAUGHT STRIPS

Controlled ventilation helps reduce condensation and damp, by letting fresh air in when needed. However, draughts are uncontrolled: they let in too much cold air and waste too much heat. To draught-proof your home you should block up unwanted gaps that let cold air in and warm air out.

- ✓ You will need to wash and dry the window / door frame, using a sponge or cloth to ensure the surface is clean, so the draughts strips stick properly to the surface.



- ✓ Measure the lengths that you need and cut the draught proofing strips to size.

- ✓ Peel backing paper and apply the adhesive side of the strip onto the surface that the door or window closes onto.

- ✓ You can stick the foam strip side by side or on top of each other if your gap is wider.



- ✓ In the unlikely event that the door/window does not shut properly after installing, remove the draught proofing strips.